



IBM-5291-Cable to Pinhead-14:
 A01-1(GND);A03-3(GND);A09-4(GND);
 A08-5(Vcc+5V);A07-Shield(PE); NP-2
 A04-6(D0);B01-7(D1);B03-8(D2);B04-9(D3);
 B08-10(D4);B09-11(D5);B10-12(D6);
 A02-13(Strobe);A10-14(Out)

IBM-5291-2 Cable with DB15M connector:
 A01,A03,A09-1,2,3 (GND);
 A08-4 (Vcc+5V);A07-14(PE); NP-15;
 A04-5(D0);B01-6(D1);B03-7(D2);B04-8(D3);
 B08-9(D4);B09-10(D5);B10-11(D6);
 A02-12(Strobe);A10-13(Out)

IBM-5291: 1761211
 E.C. 98825H 31-JAN-1985
 P.N. 6110520 E.C. 528338
 IBM-5291-2: Pt.No.4176191 Model F
 DATE 15Feb.85, ID No. G7798
 EC.NO.833677 PLT.NO.J1

IC-List:
 IC1,2: 239 2102 OF 767368 C8437 S (TI) (7404)
 IC3: 239 2104 OF 767369 C8432 S (TI) (7410)
 IC4: 239 2136 SA 760573 8211 CT (NatSemi) (74154)
 IC5: 239 2138 OF 760573 A 8424S (TI) (74155)
 IC6: 5119699 IBM 52 ESD 1H400L03

\$Id: kbdbabel_doc_ibm5291_kbd.sch,v 1.9 2009/02/06 20:59:46 akurz Exp \$

TITLE IBM 5291 Terminal Keyboard Schematic	
FILE: License: CC-BY-SA 3.0	REVISION:
PAGE 1 OF 1	DRAWN BY: www.kbdbabel.org